CALIBRATE YOUR TOUCH SCREEN

Making the pen work

1. Click once on the **Start** button.

2. Type **calibrate** into the Search box.

3. Click on the item called **Calibrate the screen for pen or touch input**.



4. Click the **Calibrate…** button







To provide calibration samples, tap the crosshair each time that it appears on the screen.

Right-click anywhere on the screen to return to the last calibration point. Press the Esc button to close the tool. Do not change your screen orientation until you have completed the calibration process.

5. Use your **tablet pen** to tap the screen in the middle of each cross hair.

   Make sure you touch the screen with the pen straight-on rather than an angle for the **optimum calibration**.

6. Click **Yes**.

Your screen is now calibrated. Enjoy!